

## **Husqvarna TS 66 R**

**Pièces de rechange**

**Spare parts**

**Ersatzteile**

**Piezas de repuesto**

**Ricambi**


**Onderdelen**


**Reservdelar**

**Peças sobresselentes**



No.	Pos.	Description	No.	Pos.	Description
543040480	A	Right angle support	543850078	B	Indexable handle
543040485	B	Bearing axle	543850080	B	Electric cord + plug
543040486	B	Excentric bearing axle	543850083	B	Rubber hose, o.d. 10mm x 2mm thickness
543040491	B	Small mud flap	543850093	B	Washer 16x1,5
543040496	A	Stop wire	543850099	B	Washer 8x1,5
543040499	B	Handle rubler	543850100	B	Water tap
543040500	B	Spring	543850198	B	Fan Cover
543040502	A	Plug	543850226	A	Plastic handle
543040503	B	Water pump AP1200-230V	543850227	B	Adjustable bearing
543040511	A	Short ruler	543850228	B	Fixe bearing
543040512	A	Mud flap support	543850229	B	Complete head
543040513	A	Mud fla	543850325	B	Internal Flange
543040517	A	Pivot right angle	543850327	B	External flange
543044585	A-B	Screw TH 5x10	543850328	B	M12 left side thread c.l 8.8
543044586	A	ScrewsTH 5x16	543850447	A	Spare part List
543044588	A	Screw TH 6x10	543850448	A	Operator's manual
543044589	B	Screw, Hex M6X12	543850449	B	Motor 0.9 Kw-230v
543044599	B	Screw TH 8x16	724128751	B	Screw M4x8 Pan head
543044600	B	Screw TH 8x20	724332751	A	Screw, countersink bolt M5x12
543044706	A-B	Washer M5	725536801	A	Screw, inhex M6x16
543044707	A	Washer M6	732211801	A	Nylon lock nut M8
543044708	A	WASHER, 8	735214601	A-B	Washer Split lock M5
543044708	B	WASHER, 8	735215301	B	Washer Split lock M6
543044709	B	WASHER, 10	738219804	B	Ball bearing 608RS
543044718	A-B	Washer Large M8			
543044750	A-B	Nut HU8			
543046033	A	RUBBER PAD			
543046080	A	Wing screw M8 x 20			
543046082	A	Wing screw M8x12			
543046087	A-B	Wing screw M6x16			
543072749	B	Wire Protection			
544942201	A	Tank assy			
543072844	A	Feet d/35			
543072845	A	Feet pad			
544943001	A	Equiped arm support			
543072847	A	Table			
543072848	A	Rule			
543072849	A	Rail			
544942301	A	Right Arm			
544942401	A	Left arm			
544942501	B	Bearing support assembly			
543072853	B	Bumper			
543072854	B	Axle			
544942601	B	Motor support			
544942801	B	Intérieur hood assy			
544942901	B	Outside Hood			
543072858	B	Handle tube			
543072859	A	Extension assy			
543072861	B	Tightening rod			
543850066	B	NUT M5			







[www.husqvarnacp.com](http://www.husqvarnacp.com)